SP : SPEEDOMETER LIGHT
TA : TACHOMETER LIGHT
N : NEUTRAL INDICATOR LIGHT
H : HIGH BEAM INDICATOR LIGHT
O : OIL PRESSURE INDICATOR LIGHT
R : TURN SIGNAL INDICATOR LIGHT(R)
L : TURN SIGNAL INDICATOR LIGHT(L)
FI : FI INDICATOR LIGHT
OD : OD INDICATOR LIGHT
W : ECT INDICATOR LIGHT

(OPTIONAL PARTS)
GRIP HEATER
HANDLEBAR SWITCH (R)
IGNITION SWITCH
ENGINE STOP SWITCH
FRONT BRAKE SWITCH
STARTER SWITCH
OIL PRESSURE SWITCH
REAR BRAKE SWITCH
FUEL PUMP
FUEL PUMP RELAY
TO SENSOR
AP SENSOR
ECM
SPEEDOMETER
IGNITION COIL #1
IGNITION COIL #2
FRONT TURN SIGNAL LIGHT (R)
HEADLIGHT (R)
HEADLIGHT (L)
FRONT TURN SIGNAL LIGHT (L)
REAR TURN SIGNAL LIGHT (R)
BRAKE LIGHT/ TAILLIGHT
LICENSE LIGHT
REAR TURN SIGNAL LIGHT (L)
HORN
HORN BUTTON
TURN SIGNAL SWITCH
DIMMER SWITCH
FAN MOTOR SWITCH
FAN MOTOR
CLUTCH LEVER POSITION SWITCH
HANDLEBAR SWITCH (L)
STV ACTUATOR
ECT SENSOR
CMP SENSOR
GEAR POSITION SWITCH
FUSE BOX
1. HEAD HI 15A
2. HEAD LO 15A
3. METER 10A
4. IGNITION 15A
5. SIGNAL 15A
6. FAN 15A
STP SENSOR
IAT SENSOR
IAP SENSOR
SPEEDOMETER SENSOR
SIDE STAND SWITCH
CKP SENSOR
GENERATOR
REGULATOR/ RECTIFIER
STARTER MOTOR
1:MAIN 30A
STARTER RELAY
12V
BATTERY
TP SENSOR
#1 INJECTOR
#2 INJECTOR